


Spare Parts List

CP 1240 Demolition tool





2005-09 No. 9800 0536 01

©Copyright Stockholm, Sweden CP 1240 Spare parts list

Contents	Pages
General information	4
Exploded views and tables	6-7

Spare parts list CP 1240

GENERAL INFORMATION

Welcome! Protect your investment in the world's finest air tools. Use genuine CP replacement parts.

The purchase of replacement parts for your CP tools deserves the same good judgment that resulted in the buying of the tools themselves. Each genuine CP part is made from carefully selected and inspected material, subjected to sophisticated machinery and finishing processes and heat-treated to produce just the right combination of hardness, ductility and impact resistance for its intended use. All parts are manufactured concurrently with those used in production tools, and are identical to them. The use of parts other than genuine CP replacement parts can lead to substandard performance, early failure, possible damage of other parts and, in some instances, unsafe conditions.


To reduce the risk of injury, read and understand the Operating Instructions manual and the percussion tool safety instructions before operating the tool.

CP 1240 is a pneumatic tool designed to deliver the power and durability necessary for a variety of construction and plant maintenance work such as breaking heavy concrete, reinforced concrete, frozen ground, macadam, boulders and pavement. It has a four-bolt back head design.

CP 1240 Spare parts list

Spare parts list CP 1240

EXPLODED VIEW OF CP 1240 S & VRS



CP 1240 Spare parts list

Ref. No.	Ordoring No.	Otv	Description
Rei. No.	Ordering No.	Qty.	Description
1	F816345	2	Grip - Rubber
2 3	F815126 R075031	1 1	Backhead assembly (Includes item No. 2, 3, 4,5,6 & 7) Plug - Oil
4	C036901	1	Plug - Oil regulator
5 6		1	Backhead
6	F814725	1	Lever - Throttle
7 8	R133433 R003069	2 4	Pin - Throttle lever Nut - Hex.
9	R000550	4	Lock washer
10	R085259	1	Washer - Take up
11 12	R122977 R092904	1 1	Valve case assembly (Includes item No. 12, 13, 14 & 15) Case - Valve
13	P083094	2	O-ring
14	R122975	1	Valve
15 16	R122976	1	Guide - Valve
16 17	R092894	1 1	Valve - Throttle (Includes item No. 17, 18 & 19) Valve - Throttle
18	R098368	1	Seal - Throttle valve
19	R098369	1	Ring - Valve seal retaining
20 21	R005717 R047965	1 1	Spring - Throttle valve Seal - Cylinder
22	R092896	4	Bolt - Backhead
23		1	Cylinder
24	R085269	1	Swivel - Air inlet
25 26	R110317 P103521	1 1	O-ring O-ring
27	R000530	i	Nut - Inlet swivel
28	F037790	2	Bolt - Fronthead
29 30	R000127 R092907	1 1	Piston Bushing - Anvil block
30 31	R092907 R096123	1	Block - Anvil
32	R092918	1	Fronthead (1 1/4" Hex.) (Includes item No. 33)
33	R040635	1	Bushing - Fronthead (1 1/4")
34 35	R092917 R090122	1 1	Fronthead (1 1/8" Hex.) (Includes item No. 35) Bushing - Fronthead (1 1/8")
36	Z3629448	i	Side bolt kit, includes one pair of complete bolt assembly
		_	(Item No. 28, 37, 38 & 39)
37 38	R092915 R096059	2 2	Spring - Fronthead Lock - Fronthead nut
39	F037789	2	Nut - Fronthead holt
40	Z8320448	1	Latch kit (Includes item No. 41, 42, 43, 44, 45, 47 & 48)
41	P008999	1	Lock nut
42 43	R076562 R092911	2 1	Bushing - Retainer bolt Spring - Latch plunger
44	R092910	1	Plunger - Retainer latch
45	R076853	1	Bolt - Retainer latch
46 47	R092909	1	Latch - Retainer complete (Includes item No. 47 & 48)
47 48	R050894	1 1	Bushing - Retainer latch Latch - Retainer
49	K3206448	<u>i</u>	Muffler complete (Includes item No. 50 & 51)
50	F814004	1	Hood - Muffler
51 52	R117415 R043649	4 1	Screw - Allen cap Block - Driving
53	R043644	1	Fronthead (Spike driver) (7.69")
54	R145778	1	Backhead assembly (Includes item No. 55 to 75 & 4, 18, 19 & 20)
55	R157669	1	Cover - Buffer
56 57	R145866	1	Pin - Lever
57 58	R145781 R145788	1 2	Lever Grip
59	R146841	2	Handle
60	R145861	3	Steel washer
61	R004975	1	Oil - Plug sq.hd.
62	Q3217400	1	Plug
63	0108 1535 00	1	Pin - Roll
64 65	R147757 R157670	2 2	Spring Pin - Stepped
66	K13/0/0	1	Backhead
67	R147756	1	Gasket
68	R138490	1	Upper valve lid
69	R138489	1	Valve case
70 71	R138488	1	Valve
71 72	R145787 R137341	1 2	Lower valve lid O-ring
72 73	R157341 R154983	1	O-ring
74 74	R145782	1	Throttle valve (Includes item No. 75, 18 & 19)
75		1	Throttle valve
76 77	R147441	1	Block - Driving - Ext. Ig.
77	R147439	1	Fronthead (Spike driver) (12.69")



2005-09 No. 9800 0536 01

©Copyright Stockholm, Sweden

